

# Multi-Color Panel Design in Flow Cytometry (2022)



Elabscience®



**Elabscience Biotechnology Inc.**

🌐 [www.elabscience.com](http://www.elabscience.com)

☎ 1-240-252-7368

📠 1-240-252-7376

✉ [marketing@elabscience.com](mailto:marketing@elabscience.com)

📍 14780 Memorial Drive, Suite 216, Houston, Texas 77079.

**Elabscience Biotechnology Inc.**

[www.elabscience.com](http://www.elabscience.com)



# Contents

## | 01 Panel Design Principles

- Balance Antigen Density and Fluorescence Brightness ----01
- Avoid Spectral Overlap among Fluorescence -----01
- Minimize the Complexity of Analysis -----01
- Use Tandem Dyes Carefully -----01
- Cautions with Acidic Buffer and Fixation -----01

## | 02 Steps of Multi-Color Panel Design

- STEP 01 Select the Target Markers -----03
- STEP 02 Check the Instrument Specification -----08
- STEP 03 Check Fluorescence Information -----09
- STEP 04 Pair Antigen with Fluorescence -----13

## | 03 Cases of Multi-Color Panel Design

- Mouse Spleen T Cells (3 Panels) -----15
- Mouse Spleen Treg (3 Panels) -----16
- Human Peripheral Blood T Cells (4 Panels) -----17
- Human Peripheral Blood Treg (6 Panels) -----18
- Human Peripheral Blood Th1 (3 Panels) -----19

## | 04 Data Analysis Services

- Elabscience® Provides Professional Flow Cytometry Data Analysis Services -----20


# ABOUT US

Elabscience® specializes in immunodiagnostic technology for life science community. We have complete platform for R&D and manufacturing. At the same time, we have in house QC for every product, endeavoring to keep your experiment results more consistent and precise. Through unremitting effort and development, our customers have spread in more than 100 countries all over the world.

Elabscience® major products cover Recombinant Proteins, Peptides, FCM Antibodies, Antibodies, ELISA Kits, Cell Function Detection Assays, CLIA Kits, Labeling Kits, Metabolism Assay Kits, Other Reagents, Food Safety Kits, Chromatographic Media, Cell Culture Products.

Elabscience® also offers custom services for our customers including Protein Service, Polyclonal Antibody Service, Peptide Service and Gene Synthesis.

## 01 Panel Design Principles



### 🔍 Balance Antigen Density and Fluorescence Brightness

High abundance antigen + Dim Fluorescence.  
Low abundance antigen + Bright Fluorescence.

### 🔍 Avoid Spectral Overlap among Fluorescence

Low abundance antigen can be detected in non-interference channel.  
High abundance antigen must be detected in channels that do not interfere with other channels.

### 🔍 Minimize the Complexity of Analysis

Allow the spillover of mutually exclusive antigens.  
Allow the spillover of co-expressed antigens with highly abundance.  
Allow the spillover of offspring to their parents, but not the opposite.

### 🔍 Use Tandem Dyes Carefully

Tandem dyes are necessary in multi-color panel design.  
Easily degraded when exposed to light or undergoing fixation.  
Follow protocols strictly to avoid tandem dyes degradation.

### 🔍 Cautions with Experiment Working Buffers

The acidic buffer or fixing step may destruct some dyes.  
eg: FITC is susceptible to low pH condition  
Fixation and extended storage lead to dye degradation.

## 02 Steps of Multi-Color Panel Design



STEP 01


Select the Target Markers

Refer to relevant literature and select the target markers

| Human                | Marker                           |
|----------------------|----------------------------------|
| B Cells              | CD19                             |
| T Cells              | CD3, CD4, CD8                    |
| Treg Cells           | CD4, CD25, CD127                 |
| Th1/Th2/Th17 Cells   | CD4, IFN- $\gamma$ , IL-4, IL-17 |
| Dendritic Cells      | CD1c, CD83, CD141, CD209, MHC II |
| Natural Killer Cells | CD3-, CD16, CD56                 |
| Macrophage           | CD11b, CD68, CD163               |
| Monocyte             | CD14, CD16, CD64                 |
| Plasma Cells         | CD138                            |
| Red Blood Cells      | CD235a                           |

| Mouse                | Marker                           |
|----------------------|----------------------------------|
| B Cells              | CD19                             |
| T Cells              | CD3, CD4, CD8                    |
| Treg Cells           | CD4, CD25, Foxp3                 |
| Th1/Th2/Th17 Cells   | CD4, IFN- $\gamma$ , IL-4, IL-17 |
| Dendritic Cells      | CD11c, MHC II                    |
| Natural Killer Cells | CD3-, CD49b (clone DX5) or NK1.1 |
| Macrophage           | F4/80, CD11b, CD80, CD86, CD206  |
| Monocyte             | CD11b, CD115, Gr-1, Ly-6C        |
| Plasma Cells         | CD138                            |
| Red Blood Cells      | TER-119                          |


Check the marker locations



- ☞ Generally speaking, most CD markers are located on the surface of cytomembrane. Cytokines, such as interleukins and interferon (IFN- $\alpha$ , IFN- $\beta$  and IFN- $\gamma$ ), tumor necrosis factors (TNF- $\alpha$ , TNF- $\beta$ ) etc., are intracellular markers. And Foxp3 is the most popular intranuclear marker.
- ☞ For the intracellular and intranuclear markers, the cell needs to be fixed and broken before staining. If there is any intracellular or intranuclear maker, by conventional method, the first step is to stain the surface markers. Because "fixation" is easy to damage the tandem fluorescein, tandem dyes shall be not used in this step.


### Check the antigen abundance

The antigen abundance can be roughly divided into three categories according to the expression of the corresponding antigen on/ in the cell types:




Easy to identify and antigens with obvious separation of negative-positive groups which can be easy distinguished. eg: CD3, CD4, CD19, etc..

Negative and positive groups can be easy distinguished



Easy to identify, high abundance antigen and often expressed continuously. eg: CD27, CD28, CD45RA, CD45RO, etc..

High abundance antigen and expressed continuously



Low abundance, active marker, or unknown but key markers. eg: CD25, STAT5, Foxp3, etc..


Low expression

### ++Common cell surface antigen density++

| Cell Type   | Marker | Density | Cell Type         | Marker        | Density |
|-------------|--------|---------|-------------------|---------------|---------|
| Lymphocyte  | CD3    | ++      | B cells           | CD19          | ++      |
|             | CD4    | ++      |                   | CD20          | +++     |
|             | CD8    | ++      |                   | CD21          | ++++    |
|             | CD19   | +       |                   | CD22          | ++      |
| T cells     | TCR    | +++     |                   | HLA-DR        | +++     |
|             | CD2    | ++      |                   | CD11a         | ++      |
|             | CD3    | +++     | CD40              | +             |         |
|             | CD5    | ++      | CD86              | ++            |         |
|             | CD7    | ++      | CD80              | +             |         |
|             | CD45   | ++++    | Dendritic cells   | CD11a         | ++      |
| CD4+T cells | CD4    | +++     |                   | CD40          | ++      |
|             | CD28   | ++      |                   | CD80          | +++     |
|             | CCR5   | ++      | CD86              | ++++          |         |
| CD8+T Cells | CD8    | ++      | NK Cells          | CD56          | ++      |
|             | CD28   | ++      | Red blood cells   | Glycophorin A | +++++   |
| Monocyte    | CD14   | +++     | Neutrophils       | CD14          | +       |
|             | CD32   | ++      |                   | CD16          | ++++    |
|             | CD64   | ++      | Basic granulocyte | CD23          | ++      |

“+” means the antigen density is below 10,000.  
 “++” means the antigen density is 10,000~100,000.  
 “+++” means the antigen density is 100,000~200,000.  
 “++++” means the antigen density is 200,000~300,000.  
 “+++++” means the antigen density is above 300,000.

Check the markers interrelation



The markers' relationship includes mutual exclusion, co-expression, offspring and parents, etc.

- ☰ Mutual exclusion means that two antigens will not be expressed on one cell at the same time, that is, if there is Protein A, there will be no Protein B, or if there is Protein B, there will be no Protein A. And mutually exclusive antigens allow fluorescence spillover. eg: T cells are divided into CD4+ T cells and CD8+ T cells. CD4+ T cells express CD4 but not express CD8, and CD8+ T cells express CD8 rather than CD4.
- ☰ Antigen co-expression means that two antigens are expressed on the same cell. eg: Mouse Treg cells express CD25 and Foxp3 at the same time. Co-expressed but highly expressed antigens allow spillover.
- ☰ If the markers are offspring and the parents. Parents must be analyzed first. It means that the offspring antigen is analyzed on the basis of the parent antigen. eg: All T cells express CD3, and T cells are divided into CD4+ T cells and CD8+ T cells. In this case, CD3 is the parent, CD4 and CD8 are the offspring. Generally speaking, the spillover of offspring to parents is allowed, but spillover of parents to offspring is forbidden.

STEP 02

Check the Flow Cytometry Information

| Channel and optional fluorescence                       |            |                   |                                    |
|---|------------|-------------------|------------------------------------|
| Flow cytometry  | Excitation | Detector (Filter) | Common fluorescence                |
| Take the flow cytometry with double laser as an example | 488nm      | 530/30            | FITC、AF488                         |
|   |            | 575/26            | PE                                 |
|   |            | 610/20            | PE/TR、PE/AF594                     |
|   |            | 695/40            | PerCP/Cyanine5.5、PE/Cyanine5、PerCP |
|   |            | 780/60            | PE/Cyanine7                        |
|   | 633nm      | 660/20            | APC、AF647                          |
|   |            | 730/45            | AF700                              |
|   |            | 780/60            | APC/Cyanine7、ER780                 |

Different manufacturers or different models have different configurations, even if the same model may have different configurations. When designing the panels, we must check the configuration of flow cytometry before we select appropriate fluorescence. It is suggested to check the information as below:

- ① Excitation. There are several lasers can be used as excitation wavelength. The common flow cytometry lasers are 405nm, 488nm, 561nm, 633nm, etc..
- ② Detector. Detectors are used to analyze emission wavelength.

Fluorescence wavelength information

| Fluorochrome     | Fluorescence Emission Color | Excitation Laser Lines (nm) | Excitation Max(nm) | Emission Max(nm) |
|------------------|-----------------------------|-----------------------------|--------------------|------------------|
| EV450            | Blue                        | 405                         | 410                | 450              |
| AF488            | Green                       | 488                         | 495                | 520              |
| FITC             | Green                       | 488                         | 490                | 530              |
| PE               | Yellow                      | 488, 532, 561               | 495, 565           | 575              |
| PI               | Orange                      | 488, 532, 561               | 536                | 617              |
| PE/TR            | Orange                      | 488, 532, 561               | 495,565            | 620              |
| PE/AF594         | Orange                      | 488, 532, 561               | 495,565            | 615              |
| 7-AAD            | Red                         | 488, 532, 561               | 546                | 650              |
| Cyanine 5        | Red                         | 633, 635, 640               | 650                | 670              |
| APC              | Red                         | 633, 635, 640               | 650                | 660              |
| AF647            | Red                         | 633, 635, 640               | 650                | 670              |
| PE/Cyanine5      | Red                         | 488, 532, 561               | 495, 565, 655      | 670              |
| PerCP            | Red                         | 488                         | 440, 480, 675      | 675              |
| PerCP/Cyanine5.5 | Red                         | 488                         | 440, 480, 675      | 675              |
| PE/Cyanine5.5    | Far Red                     | 488, 532, 561               | 495, 565, 675      | 690              |
| PE/Cyanine7      | Infrared                    | 488, 532, 561               | 495, 565, 755      | 775              |
| ER780            | Infrared                    | 633, 635, 640               | 625                | 765              |
| APC/Cyanine7     | Infrared                    | 633, 635, 640               | 650, 760           | 780              |

STEP 03


Check Fluorescence Information

- ☞ Check the fluorescein excitation and emission wavelength, and confirm which fluorescence can be used on the flow cytometry according to the information of laser and detector.
- ☞ Check the relative brightness of the selected fluorescence.
- ☞ Check the spillover among the fluorescence.
- ☞ Check the characteristics of different fluorescence, and select the appropriate fluorescein according to the experimental purpose and requirements.

Relative brightness of common fluorescence

|                    | Very Bright                            | Bright                       | Moderate                          | Dim                   |
|--------------------|--|------------------------------|-----------------------------------|-----------------------|
| Blue<br>(488 nm)   | PE<br>PE/Cyanine7<br>PE/TR<br>PE/AF594 | PE/Cyanine5<br>PE/Cyanine5.5 | FITC<br>AF488<br>PerCP/Cyanine5.5 | PerCP                 |
| Red<br>(633 nm)    |  | APC<br>AF647                 |                                   | ER780<br>APC/Cyanine7 |
| Violet<br>(405 nm) |  |                              |                                   | EV450                 |

Overlap information of fluorescence



Fluorescence characteristics

| Fluorescence     | Characteristics   |
|------------------|---|
| FITC             | Easily affected by pH value. When the pH value decreases, the fluorescence intensity also decreases.                                    |
| AF488            | Resistant to light and remains stable in a wide pH value (pH4~10).  |
| PE               | High brightness, relatively stable.   |
| APC              | High brightness, less stable than PE.   |
| PerCP/Cyanine5.5 | Relatively stable (brightness and fixation) tandem dye.   |
| PE/Cyanine 5     | High brightness, easy to quench, not suitable for fixation, no matching with APC.   |
| ER780            | Brightness is better than APC/Cyanine 7, which can replace APC/Cyanine 7. Suitable for fixation and has less spillover to APC detector. |
| APC/Cyanine 7    | Weak brightness, not suitable for the analysis of low abundance antigens. Easy to quench and not suitable for fixation.                 |
| PE/Cyanine7      | High brightness, easy to quench, not suitable for fixation, no overlap with FITC, little interference and spillover with APC.           |




STEP 04


Pair Antigen with Fluorescence

Balance Antigen Density and Fluorescence Brightness

For high abundance antigen, weak or strong fluorescein can be selected. As shown in the figure, high abundance antigen CD3 selects weak fluorescein FITC or strong fluorescein APC, there is little effect on the results.




For low abundance antigen, strong fluorescein must be selected. As shown in the figure, weak fluorescein PerCP is selected by low abundance antigen CD25, leading to the inseparability of Negative-Positive cell groups. If strong fluorescein PE is used, positive cell groups can be obvious to observe.



Avoid Spectral Overlap between Fluorescence

Different fluorescence may have spectral overlap. Try to use the fluorescence combination with less spectral overlap in color matching, which can reduce the complexity of data analysis. When the overlap occurs, fluorescence compensation can only eliminate the background. For the reduced sensitivity of the disturbed detectors, it does not work.




No interference

Serious interference

### 03 Cases of Multi-Color Panel Design

#### Case1: Mouse Spleen T cells (3 Panels)

| Marker | Fluorescence | Clone No. | Cat. No.    |
|--------|--------------|-----------|-------------|
| CD3    | EV450        | 17A2      | E-AB-F1013Q |
| CD4    | APC          | GK1.5     | E-AB-F1097E |
| CD8    | ER780        | 53-6.7    | E-AB-F1104S |




**TIPS:**

1. Easy to distinguish the Negative-Positive cell groups, and there is no need for single staining tubes for compensation.
2. CD3 / 4 / 8 cells are easy distinguished, and generally speaking, isotype control is unnecessary.
3. The key factor of this experiment is the lysis of red blood cells. Excessive or insufficient lysis of red blood cells will lead to the unclear lymphocyte groups.

#### Case2: Mouse Spleen Treg (3 Panels)

| Marker | Fluorescence | Clone No. | Cat. No.    |
|--------|--------------|-----------|-------------|
| CD4    | FITC         | GK1.5     | E-AB-F1097C |
| CD25   | APC          | PC-61.5.3 | E-AB-F1102E |
| Foxp3  | PE           | 3G3       | E-AB-F1238D |




**TIPS:**

1. Mouse Treg market is CD4+ CD25+ Foxp3+.
2. CD4+ cell group is obvious, and there is no need of isotype control. But CD25 and Foxp3 groups are not obvious, and isotype controls are needed.
3. There is fluorescence spillover, and it is necessary to set single staining tubes for compensation.
4. Inappropriate use of Fixation/Permeabilization buffer may cause high background and unclear cell clustering. Please be careful.

Case3: Human Peripheral Blood T Cells (4 Panels)


| Marker | Fluorescence | Clone No. | Cat. No.    |
|--------|--------------|-----------|-------------|
| CD45   | EV450        | HI30      | E-AB-F1137Q |
| CD3    | APC          | OKT3      | E-AB-F1001E |
| CD4    | FITC         | RPA-T4    | E-AB-F1109C |
| CD8a   | PE           | OKT-8     | E-AB-F1110D |



- TIPS:**
1. For human peripheral blood T cells, it is suggested to use CD45, which can easily gate the lymphocyte group.
  2. The cell groups are obvious, and there is no need to set single staining tubes for compensation.

Case4: Human Peripheral Blood Treg (6 Panels)


| Marker | Fluorescence     | Clone No. | Cat. No.    |
|--------|------------------|-----------|-------------|
| CD45   | EV450            | HI30      | E-AB-F1137Q |
| CD3    | ER780            | OKT3      | E-AB-F1001S |
| CD4    | FITC             | RPA-T4    | E-AB-F1109C |
| CD8a   | PerCP/Cyanine5.5 | OKT-8     | E-AB-F1110J |
| CD25   | PE               | BC96      | E-AB-F1194D |
| CD127  | AF647            | A019D5    | E-AB-F1152M |



- TIPS:**
1. Detecting human Treg by CD127 is no need of Fixation/Permeabilization step.
  2. Gate the lymphocyte directly through CD45 and SSC, and then analyze the proportion of CD4+ CD25+ CD127-/low cells. Treg cells account is about 3% ~ 10% of lymphocytes in normal human peripheral blood.
  3. It is suggested to set single staining tubes for compensation.

Case5: Human Peripheral Blood Th1 (3 Panels)

| Marker | Fluorescence     | Clone No. | Cat. No.    |
|--------|------------------|-----------|-------------|
| CD3    | EV450            | OKT3      | E-AB-F1001Q |
| CD8a   | PerCP/Cyanine5.5 | OKT-8     | E-AB-F1110J |
| IFN-γ  | FITC             | B27       | E-AB-F1196C |



**TIPS:**

- 1.PMA stimulation can lead to CD4 expression down on the surface of human T cells. Therefore, we define CD4+ T cells by gating CD3 and CD8, and CD3+ cd8- IFN-γ+ group is Th1 cells.
- 2.IFN-γ isotype control is necessary, since generally this marker abundance is not high.
- 3.Inappropriate use of Fixation/Permeabilization buffer may damage the cells. It is suggested to re-suspend the cells after centrifugation, and then add the permeabilization buffer to reduce cell damage.

04 Data Analysis Services

You can also provide the original data of experimental results and logical relationship of markers to technical support. We can provide professional data analysis services for you.

- 01 Customer provides basic information.
- 02 Estimate experimental design and data integrity.
- 03 Data analysis.
- 04 Provide analysis results.